

#335

QUOTATION

FOSTER COACH SALES, INC

Quote For:
NAPERVILLE FIRE DEPARTMENT
400 SOUTH EAGLE
NAPERVILLE, IL 60566
% JIM INGLESE

Ship To:
FOSTER COACH R
STeve Foster

>>>NWMC Truck<<<<<<
>>>Prev. Unit 5749<<<<

Exp. Date: 08/25/2005 Job No: 6907
Quote No: ORDER-0009

02/26/2006

Page 1

PART NO	DESCRIPTION
	<p>== AD-170, 170" x 96", Type I - 5.006 06/15/05 ==</p> <p>SHOP NOTE: >>>NWMC Truck<<<<<< >>Previous unit # 5749<<<< >>>NO WOOD PRODUCTS<<<<<<</p>
01-00-00	VIN #
01-02-04	<p>Factory Discount/Concession NWMC CONFERENCE DISCOUNT</p> <p>SHOP NOTE: Approval Letter on file from Kevin Noble dated 9-28-05</p>
10-02-08	<p>2006 Base Conversion, AD-170, Type I AD</p> <p>SHOP NOTE: This is a 2006 conversion as order was received on 12-12-05 and was not on the 2005 conversion approved list.</p>
10-08-08	Completed Vehicle Dim/Curb Weight/Payload Allowance AD-170
11-06-12	72" Headroom (AD-170)
12-00-26	<p>EXTERIOR "A" COMPARTMENTS - RIGHT SIDE (72" HR) AD-170</p> <p>SHOP NOTE: LOCATION: Exterior compartments, passenger side. SPECIAL BODY PER PRINTS</p>
12-02-02	Type I, Class I, MD, Two-Door Cab/Chassis Tech Requirements
	*** CHASSIS MAKE & MODEL ***
12-10-10	<p>Dealer Supplied Chassis</p> <p>SHOP NOTE: Chassis spec is received and on file 2006 4300SBA LP 4x2</p> <p>NOTE - SPECIAL WHEELBASE AND CAB TO AXLE DIMENSIONS.</p> <p>ENG. NOTE: Please note: Part # 60-14-08, condenser, is add for use with Navistar chassis. Please contact Medtec to ensure proper chassis is ordered</p> <p>NOTE:</p>

PART NO	DESCRIPTION
	INSTRUCTION: 175" wheelbase 20,000 LB GVRW 107.9" Cab to Axle
12-10-11	DISCOUNT for NWMC Dealer Supplied Chassis SHOP NOTE: Letter dated 9-28-05 from Kevin Noble is on file.
12-13-16	<input checked="" type="checkbox"/> Rear Air Ride (OEM) System - (AD Units) SHOP NOTE: <input checked="" type="checkbox"/> HAS 120 air suspension. <input checked="" type="checkbox"/> OEM dump valve in dash. <input checked="" type="checkbox"/> Dump automatically activated with the streetside rear door jamb switch. <input checked="" type="checkbox"/> Wire battery hot at all times. <input checked="" type="checkbox"/> Red indicator light in front console to indicate low PSI. <input checked="" type="checkbox"/> A dump cancel switch installed by the passenger rear entry door.
14-02-00	*** CHASSIS COMPONENTS ***
14-24-99	KUSSMAUL 091-84 AUTO THROTTLE SHOP NOTE: Install an Kussmaul 091-84 Auto-throttle system wired to the park position of the transmission.
16-02-00	*** CHASSIS INTERIOR COMPONENTS ***
16-12-04	<input checked="" type="checkbox"/> Bulkhead Cab Wall, OEM Wall To Match Dash
16-14-04	<input checked="" type="checkbox"/> Cab Sign, "No Smoking, Oxygen Equipped" & "Fasten Seatbelts"
	SHOP NOTE: <input checked="" type="checkbox"/> INSTRUCTION; (1) on top of floor console, at rearward edge, toward walkthru.
16-20-99	FLOOR CONSOLE LIKE LAST THREE UNITS--PER PRINT SHOP NOTE: MAKE MAP BOX LIKE PRINT AND LAST UNIT 5749 INSTRUCTION; Install SPECIAL floor-mounted console. Install switch panel in dash. USE OLD STYLE rocker switch panel.
	ENG. NOTE: Specify design and location. Contact factory for pricing and availability prior to offering to customer.
	NOTE: Special front console with recessed video monitor for back-up camera, mounting platform for Mobile Data computer, radio & siren heads, and document storage.
	See Prints for exact layout and required dimensions.
16-21-00	<input checked="" type="checkbox"/> Battery Switch - TST Commander 350 With 5 Minute Timer
16-24-02	<input checked="" type="checkbox"/> Chassis OEM Engine Block Heater, SHOP NOTE: DO NOT WIRE BLOCK HEATER TO SHORELINE
16-24-99	SET UP FOR NEDERMAN EXHAUST SYSTEM SHOP NOTE: DEALER TO INSTALL SYSTEM NOTE:

mount brkt shipped loose if want to change

mount right. 24" c to c

PART NO	DESCRIPTION
	Exhaust to terminate on streetside in front of the rear tires. Mount at right 90 degree angle to body like previous unit 5749.
	*** CHASSIS EXTERIOR ACCESSORIES ***
18-06-04	✓ Wheel Simulators, Dicor - Stainless Steel
18-12-02	✓ Tire Fill Extensions (4)Dicor, For Rear Inside/Outside Tires
	SHOP NOTE:
	*** 12 VOLT ELECTRICAL SYSTEMS AND COMPONENTS ***
20-02-02	✓ Vehicle Wiring, Type I, Class I
20-04-02	✓ Alternator, Leece Neville 270 Amp - With Warranty
20-06-02	Wiring Module, Angled Electrical Cabinet
21-02-00	Portable Equipment Charging Circuits
	SHOP NOTE:
	INSTRUCTION:
	(1) 20 amp circuit breaker.
	Run power wires from drivers seatbase to:
	(1) Circuit (power & ground) to front console - labeled on both ends "Portable Equipment Charging Circuit".
	(1) Circuit (power & ground) to behind rear switch panel - labeled on both ends: "Portable Equipment Charging Circuit". (Requires optional inverter or battery charger for full function.)
	<i>omit skip</i>
	<i>Note: omit power outlet portable charging circuit per Larry D. in lieu of printing inner fenders 9/19/06</i>
22-02-06	Sequencer/Load Manager, Main Master Emergency Functions
	SHOP NOTE:
	INSTRUCTIONS:
	Medtec sequencer and load manager.
	Standard shedding sequence.
22-04-14	Front Console, Engine Cover Mount (Rocker Type)
	SHOP NOTE:
	INSTRUCTION:
	Install Rocker style switch panel in dash like previous unit 5749
22-09-99	STANDARD THREE GROUND STRAPS
	SHOP NOTE:
	USE STANDARD GROUND STRAPS
	[3] Locations
	[2] from module to chassis frame
	[1] from engine to chassis frame.
	<i>on done skip</i>
24-02-18	✓ (3) Batteries, 1950 CCA
	SHOP NOTE:
	INSTRUCTION:
	✓ All (3) OEM batteries in the OEM location.
24-08-08	✓ Battery Conditioner, Intelli-Power #PD9180A, 80 Amp, Dual
	SHOP NOTE:
	LOCATION; IN CAB BEHIND PASSENGER SEAT
24-12-04	✓ Outlets, (2) - 12 Volt, Cigarette Style, ALS & 1st AA
	SHOP NOTE:
	INSTRUCTION:
	✓ (1) in ALS cabinet
	✓ (1) on 1st action area wall

PART NO	DESCRIPTION
	SEE PRINTS
26-10-16	<p>✓ Shoreline, 20 Amp Kussmaul Super Auto-Eject With Dynamic Dis.</p> <p>SHOP NOTE:</p> <p>LOCATION:</p> <p>✓ On PASSENGER SIDE BEHIND SIDE ENTRY DOOR</p> <p>>>>RED COVER<<<</p> <p>INSTRUCTION: INSTALL INTERIOR ACCESS PLATE FOR ACCESS TO BACK SIDE --SEE PICTURES</p> <p>(1) 115 volt 20 amp. (60Hz) Kussmaul Super Auto-eject with dynamic disconnect.</p> <p>Water-tight cover.</p> <p>SHIP LOOSE PIGTAIL</p>
26-12-24	<p>✓ Shoreline, 20 Amp Kussmaul Super Auto-Eject With Dynamic Dis.</p> <p>SHOP NOTE:</p> <p>LOCATION: >>WHITE COVER<<</p> <p>ON DRIVER SIDE REAR BETWEEN THE TURN LIGHT AND REAR MID LEVEL FLASHER--PER PRINT</p> <p>✓ MAKE ACCESS PLATE IN D-4 FOR SERVICE ACCESS BEHIND OUTLET--CAN USE VENT</p> <p>(1) additional 115 volt 20 amp. (60Hz) Kussmaul Super Auto-eject with dynamic disconnect.</p> <p>Water-tight cover.</p> <p>SHIP LOOSE PIGTAIL</p> <p>WIRE SO EITHER OUTLET CAN BE USED FOR OUTLETS AND BATTERY CHARGER</p> <p>Label each shoreline, underneath, with engraved metal label.</p>
26-16-26	<p>✓ Outlets, (3) Interior, 115 Volt AC</p> <p>SHOP NOTE:</p> <p>LOCATION:</p> <p>✓ (2) in UPPER ALS cabinet - [1] in standard location [1] --UPPER LH SIDE OF ALS.....See Print</p> <p>✓ (1) in 1st action area</p>
26-17-64	<p>Outlets, (4) 115V Additional Interior, Special Locations</p> <p>SHOP NOTE:</p> <p>✓ [1] IN-CAB ON BACK WALL BEHIND PASSENGER SEAT</p> <p>✓ [1] MID TORSO ON SQUAD BENCH, horizontally</p> <p>✓ [1] IN CABINET--1st AA OVERHEAD, LOWER SECTION, REARWARD</p> <p>✓ [1] 2ND AA, REARWARD, MOUNTED UP HIGH</p> <p>ENG. NOTE:</p> <p>Specify location. Select quantity of two (2) or more.</p> <p>NOTE:</p> <p>--SEE PRINT on special locations</p>
26-22-05	<p>✓ Spotlight, (1) Optronics "BlueEye 4000", Hand-Held, Hard Wire</p> <p>SHOP NOTE:</p> <p>LOCATION:</p> <p>Wired to dash.</p> <p>SHIP LOOSE HANGING HARDWARE.</p> <p>On GMC and Internationals wire to Passenger side of dash.</p>
26-26-04	<p>✓ Spotlight Bracket (1)</p> <p>SHOP NOTE:</p> <p>Specify Location: SHIP LOOSE--DEALER WILL INSTALL</p> <p>to be mounted 9/19/06 by Foster location - agreed upon</p>

*** AUDIO WARNING DEVICES ***

PART NO	DESCRIPTION
28-02-08	Siren & Amplifier, Whelen, #295HFS1 (HF)
	SHOP NOTE:
28-06-20	✓ Speaker, Bumper Mounted, #SA31I01D-4300
	SHOP NOTE:
	INSTRUCTION:
	Driver's Side - 4300
	MOUNT UNDER BUMPER
	USE CAST SPEAKERS
	NOTE:
	Foster Coach will warrant the siren speakers to the customer not Medtec per Steve Foster 12-5-05
28-06-22	✓ Speaker, Bumper Mounted, #SA31I01P-4300
	SHOP NOTE:
	INSTRUCTION:
	Passenger Side - 4300
	MOUNT UNDER BUMPER
	USE CAST SPEAKERS
	NOTE:
	Foster Coach will warrant the siren speakers to the customer not Medtec per Steve Foster 12-5-05
28-14-99	✓ Backup Alarm, Federal Reactor 210350 W/ Auto Reset Sw ILOS
	SHOP NOTE:
	INSTRUCTION: ILOS Preco 230
	✓ (1) Automatic reset cancel switch mounted in front switch panel. Federal Reactor 210350 77-120db back-up alarm.
	ENG. NOTE:
	Special configuration. Contact factory for pricing and availability prior to offering to customer.
29-00-02	✓ Back-up Camera and Monitor, ASA Kit 1
	SHOP NOTE:
	(1) exterior camera center mount over the rear doors under the light bar. Recess the front monitor in the cab console.
*** VISUAL WARNING DEVICES ***	
	SHOP NOTE:
	✓ >>All lights are to double flash<<
	✓ Use Whelen AFL530 Flasher ILOS Vanner Flasher
30-03-10	✓ Clearance Lights, LED, (11) With Chrome Bezel
	SHOP NOTE:
	INSTRUCTION:
	(4) lights - two on each side, of upper body corner extrusions. (5) on the rear and (2) on the front, upper body extrusions.
30-04-06	✓ Headlight Flasher, ETM "Traffic Mover Pulse"
	SHOP NOTE:
	LOCATION:
	OEM chassis headlights
30-06-02	✓ Headlight Flasher Mounting Location, Standard
	SHOP NOTE:

PART NO	DESCRIPTION
	<p>✓ LOCATION: (Standard) Flasher mounted in electrical cabinet</p>
30-06-06	<p>✓ Headlight Flasher Wiring, Standard ✓ SHOP NOTE: LOCATION: (1) switch in the front switch panel.</p>
30-09-02	<p>✓ Lights, Whelen 600 LED, Stop/Tail/Turn With Arrow ✓ SHOP NOTE: ✓ With Flanges. ✓ LOCATION: Install per print. Backup lights - LED on rear of module, in ADP kickplate. ← Tail and backup lights on rear of module, in ADP kickplate. Turn light above ADP - centered in beltline stripe.</p>
30-12-00 30-16-99	<p>✓ CHASSIS GRILLE LIGHTS Grille Lights, (2) Whelen 702*SO*RC Str/LED, Split R/C Lens ✓ SHOP NOTE: INSTRUCTION; With bezels. (2) Whelen Strobe/LED lights with split red/Clear Lens LED section of light to be RED Strobe section of light to be Clear, Mount both clears toward center</p> <p>ENG. NOTE: Specify type of lights and lens colors. Contact factory for pricing and availability.</p>
30-18-00 30-18-18	<p>NOTE: LED lights to flash per KKK through the regular flasher. Strobe lights to be powered by Whelen PE 215 power supply (D2 Compt) with a separate switch in the front console. Power supply to activate in Preemption effect in the primary mode and with the strobe effect in the secondary mode. Cancel in park.</p> <p>✓ INTERSECTOR LIGHTS Intersector Lights, (2) Whelen 400 Strobe, Red/Clear Lenses ✓ SHOP NOTE: INSTRUCTION: With Flanges. Whelen # 41LKT1 housings for the front fenders. Split Red/Clear-Lense with clear to front.</p>
30-30-00 30-30-99	<p>LIGHTBARS - FRONT OF VEHICLE Front Lightbar - WHELEN DELTA BAR WITH OPTIONS PER PRINT ✓ SHOP NOTE: INSTRUCTION: (1) switch in front switch panel. 56 3/8" long, See Lightbar Wizard for specifics. This lightbar is ILOS lightbar and NOT to match previous unit.</p> <p>ENG. NOTE: Specify configuration. Contact factory for pricing and availability prior to offering to customer. See front body light drop down box. (Part # 32-02-28.) Front body lights must be deleted with Edge Bar.</p>
32-02-00 32-02-38	<p>NOTE: ✓ Upper Deck: [4] 175 Rotators [2] outer with red filter [2] centers with black filter, Clear Lenses ✓ Lower Deck: [2] Delta Oscillators, [3] TIR6 Led modules (1-centered, 2-outboard of the center one), clear lenses</p>
32-02-00 32-02-38	<p>✓ FRONT OF BODY LIGHTS Frt Bdy Lgts, (3) Whelen (2) Super LED (1) Hlgn, R/G/R W/Fing</p>

Not LED corrected 9/19/06

Change to LED Blue lights on

Discussed

FSC to program before delivery 9/19/06

PART NO	DESCRIPTION
	SHOP NOTE: INSTRUCTION: ✓ With Flanges ✓ (2) 900 Super Red LED & lenses on upper Corners of Mouldle ✓ (1) 700 Halogen - GREEN lens on upper front center.
32-12-00	SIDE OF BODY WARNING LIGHTS SHOP NOTE: >>>Move all side body lights up as far as possible in a straight line<<<
32-16-12	✓ Side Body Lights, (4) Whelen 900 Super LED, Red With Flange SHOP NOTE: LOCATION: Red Super LED and Lense With Flanges ✓ (2) Streetside ✓ (2) Curbside
32-18-06	✓ Side Turn Lights, Whelen 700 LED SHOP NOTE: INSTRUCTION: ✓ With Flanges. ✓ Red LED & Lenses. ✓ (1) Each side of body at rear. ✓ Steady burn with DOT lights. ✓ Flash with turn signals. NOTE: MOVE DOWN FROM STANDARD LOCATION TO MATCH #6749
32-18-99	✓ WHELEN 900 GREEN HALOGEN SIDE BODY LIGHTS SHOP NOTE: Install one (1) green Whelen 900 Halogen light with flange in the center on each side of the modular body. All Green lights to have separate switch - Labeled Triage Lts. - and separate flasher. ✓ (2) Side 900's ✓ (1) Front 700 ✓ (1) Rear green light in center of rear lightbar.
32-22-00	✓ SIDE SCENE LIGHTS
32-22-07	✓ Scene Lights, (4) Whelen 900 Opti-Scene 8-32 degree (Flange) SHOP NOTE: INSTRUCTION: With Flanges. ✓ (2) Streetside ✓ (2) Curbside ✓ (1) switch in front switch panel, for each side.
32-24-02	✓ Scene Lgts Activatd, Rearmost W/Reverse & Curbside W/Side Door SHOP NOTE: INSTRUCTION: ✓ Curbside scene lights to activate with side entry door. ✓ Rearmost scene lights to activate in reverse.
34-02-00	✓ REAR BODY LIGHTS
34-10-14	✓ Rear Lightbar, Whelen, 86" Edgebar - #4500-KKKR Special SHOP NOTE: ✓ INSTRUCTION: Rear Lightbar (1) Halogen Flashers, (4) Rotators, (2) Flashing LED's & (2) Load Lights Lens Color: CR/AL/RR/Load/GH/Load/RR/AL/CR See Print

→ SKIP

PART NO	DESCRIPTION
	<ul style="list-style-type: none"> ✓ Load lights included in rear lightbar. Activate with rear doors and reverse. ✓ (1) On/off switch in front switch panel for load lights. ✓ (1) Switch in front switch panel for rear lightbar <p>NOTE:</p> <ul style="list-style-type: none"> ✓ [4] LED's to flash in a specific pattern. Left outside & Right Inside Right outside & Left inside
34-14-04	<ul style="list-style-type: none"> ✓ Rear Bdy Lgts, (2) Upper Whelen 900 Strobe, <p>SHOP NOTE: INSTRUCTION:</p> <ul style="list-style-type: none"> ✓ Red Lenses, With Flanges. <p>MOUNT IN UPPER REAR CORNERS BELOW THE REAR LIGHTBAR</p>
34-22-04	<ul style="list-style-type: none"> ✓ Rr Bdy Lgts, (2) Whelen 900 mid-hgt, 5mm Red With Fla <p>SHOP NOTE: INSTRUCTION: Red LED, Red Lense</p> <ul style="list-style-type: none"> ✓ With Flanges. ✓ MOUNT TO SHINE THRU REAR WINDOWS WIRE TO BRAKES
34-38-02 36-02-04	<ul style="list-style-type: none"> ✓ Warning Light Flash Requirements, "E-Spec" Flash Pattern <p>Strobe Supply, Whelen UPS 64LX, One (4) Head</p> <p>SHOP NOTE: LOCATION:</p> <ul style="list-style-type: none"> ✓ Mount to ceiling of D-2 compartment. For Rear Body and Intersection Strobes with switch.
36-08-99 <i>OK</i> <i>yes</i>	<p>Opticom -WHELEN PE215 STROBE PRE-EMPTION SUPPLY</p> <p>SHOP NOTE: INSTRUCTION</p> <p>WIRE TO GRILL STROBE LIGHTS — <i>change to everything on primary - secondary - all LED & put fail only</i></p> <p>MOUNT POWER SUPPLY IN TOP OF D-2</p> <p>ENG. NOTE: Special configuration. Contact factory for pricing and availability prior to offering to customer. Customer must specify: Department Name, Address, Telephone Number and Contact Person Name.</p>
36-09-06	<ul style="list-style-type: none"> ✓ Park Override With Reset Cancel Switch, In Front Sw. Panel <p>SHOP NOTE: CANCEL ALL BUT THE BOX FLASHING LIGHTS IN PARK</p> <p>ENG. NOTE: List out lights.</p>
36-14-04	<ul style="list-style-type: none"> ✓ C-Channel Rubrail Lights, (6) Whelen Strip-Lite LED Red Lens <p>SHOP NOTE: INSTRUCTION:</p> <p>(3) Whelen LED Strip-Lites shall be mounted in the rubrails, on each side of the unit. [1] switch in the front switch panel.</p>

*** BODY DESIGN AND CONSTRUCTION COMPONENTS ***

PART NO	DESCRIPTION
40-02-14	Body Design & Construction, Alum, 170" L x 93.5" H
40-07-02	Compartment & Entry Doors With Recessed Door Liner
40-08-10	Exterior Compartment Depth, 20.75"
40-10-04	Insulation, Dolphin Protective Coat, Spray Foam, Floor & Stepwell
	SHOP NOTE:
	LOCATION:
	Spray Foam Floor, & bottom and sides of stepwell.
40-12-02	Heat Shields, 18 ga. Galvanized Steel, Vapor Barrier
	SHOP NOTE:
	LOCATION:
	Below Subfloor and to bottom of floor tubes
40-12-12	Fender Insulator, Flash Patch Liner, Over Rear Wheelwells
40-14-02	Cab Connection, 16 Gauge Steel w/Exp Bellows
40-18-06	Body Mounting, Isomount Technique, 3/4" x 6" Alum, 16-Bolt
	SHOP NOTE:
	INSTRUCTION:
	3/4" x 6" alum plates, sixteen (16) bolts.
	Bolts and paired rubber isolators with steel cap and collared
	mounting nut for each chassis mounting point.
40-20-37	EXTERIOR "A" COMPARTMENTS - LEFT SIDE (72" Headroom)
	SHOP NOTE:
	LOCATION:
	Exterior compartments, driver side.
40-26-07	D1, Exterior Compartment, 23" W x 84" H
	SHOP NOTE:
	THIS COMPARTMENT TO BE SMOOTH ALUMINUM AND LYNEX APPLIED BY MEDTEC.....NO RUBBERMAT
40-32-02	D1, Door, Solid, Vertically Hinged
42-04-31	D2, Exterior Compartment, 49" W x 33" H >>special size<<
	SHOP NOTE:
	NOTE; WHEELBASE IS LONGER THAN STANDARD MEDTEC CHASSIS >>>Dealer supplied measurements to change standard double door compartment<<<
42-08-02	D2, Doors, Double, Solid, Vertically Hinged
42-10-24	D3, Exterior Compartment, Not Required At This Time
	SHOP NOTE:
42-16-54	D4, Exterior Compartment, 37" W x 65" H *
	SHOP NOTE:
	Full width and depth compartment the total height of compartment. NO NOTCHES, NO INSIDE/OUTSIDE ACCESS
	ENG. NOTE:
	Note: With this compartment you must have at least (1) fixed shelf or (1) adjustable shelf
42-18-02	D4, Doors, Double Solid, Vertically Hinged
44-04-70	P1, Exterior Compartment, 21" W x 66H" ALS
	SHOP NOTE:
	THIS COMPARTMENT TO BE SMOOTH ALUMINUM AND LYNEX APPLIED BY MEDTEC.....NO RUBBERMAT
	NOTE:
	No Can Above Floor
44-06-10	P1, Door, Solid, Vertically Hinged

PART NO	DESCRIPTION
44-12-36	Side Entry Door, 32" W x 74" H With Fire Grade ADP Step SHOP NOTE: "Dual" Firegrade ADP step.
44-14-34	Door Panel, Side Entry, Three-Piece, Formica & Stainless Steel SHOP NOTE: INSTRUCTION: Upper - Formica Center - Stainless Lower - Stainless Formica color to match interior.
44-15-00	Stepwell Light, Whelen 4" Round LED with Chrome Flange SHOP NOTE: Standard in 2006 conversion
44-16-06	Assist Handle, Side Entry, 1.5" x 90 Degree SHOP NOTE: LOCATION: Interior of side entry door. MAKE SURE IT CLEARS THE DRUG DRAWER Side entry is a 90 degree and rear doors are 45 degree at dealer request. NOTE: Install this handle like previous unit down rearward side of CS entry door window and across the bottom
44-28-18	P4, Exterior Compartment, Not Required At This Time SHOP NOTE:
44-32-28	P5, Exterior Compartment, 29" W x 84" H>>special size<< SHOP NOTE: INSTRUCTION: THIS COMPARTMENT TO BE SMOOTH ALUMINUM AND LYNEX APPLIED BY MEDTEC.....NO RUBBERMAT NOTE: NOTE; WHEELBASE IS LONGER THAN STANDARD MEDTEC CHASSIS >>>Dealer supplied measurements to change standard double door compartment<<<
44-34-02	P5, Door, Solid, Vertically Hinged
48-12-00	** REAR BODY PATIENT ENTRY DOORS **
48-12-10	Rear Entry Doors, 50" W x 63" H, Dual Tri-Mark Handles SHOP NOTE: INSTRUCTION: Driver side - non-locking. Passenger side - locking.
48-14-34	Door Panel, Rear Entry Doors, Three-Piece, Formica & Stainless SHOP NOTE: INSTRUCTION: Upper - Formica Center - Stainless Lower - Stainless Formica color to match interior.
48-16-08	Assist Handle, Brey Krause, Rear Entry, 1.5" x 45 Degree SHOP NOTE: LOCATION:

PART NO	DESCRIPTION
	Interior of rear entry door. THESE ARE TO BE 45 DEGREE EVEN THO SIDE DOOR IS 90
48-24-10	<i>(1) Clock, 6.5" Trintec, Above Rear Entry Doors - Hinged</i> SHOP NOTE: LOCATION: Above rear entry doors, on the head pad. Top hinge and bottom ball catch for easy access to change battery.
49-00-00	** WINDOWS **
49-02-99	<i>Window, Side Entry Door - GAS CHARGED ELECTRIC</i> SHOP NOTE: INSTRUCTION: 18" x 19" [1] switch by the curbside entry door to control all gas charged electric windows in the module. ENG. NOTE: Special configuration. Contact factory for pricing and availability prior to offering to customer.
49-06-02	<i>Window, Side Body Window GAS CHARGED</i> SHOP NOTE: 36" wide x 18" high. [1] switch by the curbside entry door to control all gas charged electric windows in the module.
49-08-99	<i>Windows, Entry Doors REAR--GAS CHARGED</i> SHOP NOTE: INSTRUCTIONS: 18" high x 19" wide [1] switch by the curbside entry door to control all gas charged electric windows in the module. ENG. NOTE: Special configuration. Contact factory for pricing and availability prior to offering to customer.
*** EXTERIOR COMPARTMENT COMPONENTS ***	
50-00-05	<i>Exterior Compartments, ADP With "Sweep Out" Design</i> SHOP NOTE: D1, P1 and P5 to be smooth aluminum with Lynex NOT rubbermat
50-00-99	<i>D-1, P-1 AND P-5 TO BE LYNEX</i>
50-02-02	Exterior Compartments, Gas Charged Door Hold Opens SHOP NOTE: LOCATION: On exterior compartment doors. Spring cam hold open on side entry door.
50-02-06	Exterior Compartment Doors, Tri-Mark Handles SHOP NOTE: INSTRUCTION: Tri-Mark paddle latches keyed alike.
50-03-00	Exterior O2 Vent - On O2 Compartment Door SHOP NOTE: INSTRUCTION: (1) #1031 O/2 vent - exterior compt. door - of O/2 compt. (1) small black plastic vent - interior of compt. door on door liner.
50-04-04	Exterior Compartments, Black Dri-Deck On Floor & Shelves
50-06-00	Rear Door Grabbers, Cast Products "Grabber"

PART NO	DESCRIPTION
	SHOP NOTE: INSTRUCTION: Bottom of rear entry doors.
50-06-04	Door Seals, Automotive Closed Cell Gasket SHOP NOTE: LOCATION: Exterior compartments & entry doors
50-06-12	<input checked="" type="checkbox"/> Power Door Lock System, All Doors - Compartment and Entry SHOP NOTE: INSTRUCTION: Except drawers. BY CURBSIDE DOOR--SEE PRINT
50-06-16	<input checked="" type="checkbox"/> Power Door Lock Switch, (1) Additional, Exterior Hidden SHOP NOTE: LOCATION: IN REAR LICENSE PLATE Bezel. Wire HOT all the time. ENG. NOTE: Specify location.
50-06-32	<input checked="" type="checkbox"/> Power Door Lock Switch, (1) Additional In Patient Compartment SHOP NOTE: [1] momentary switch at rear doors, curbside. ENG. NOTE: Specify location.
50-06-42	Wire Power Door Locks To OEM Chassis Door Locks SHOP NOTE:
50-07-03	<input checked="" type="checkbox"/> Stainless Steel Door Sills - All Exterior Compartments SHOP NOTE: INSTRUCTION: On upper ledge.
50-08-02	<input checked="" type="checkbox"/> Exterior Compartment Lights, Litco SHOP NOTE: INSTRUCTION: Activated by compartment doors.
50-10-02	<input checked="" type="checkbox"/> D1, (1) O2 Tank Mount, Stainless Steel Rings - "M" Cylinder SHOP NOTE: INSTRUCTION: Adjustable
50-12-04	D1, Vertical Fixed Divider for Backboard SHOP NOTE: INSTRUCTION: INSTRUCTION; Install (1) aluminum, full height fixed divider. Lynex, Aluminum Finish - DO NOT COVER WITH RUBBER. Mount 10" ID from forward wall to backboard divider. Make front area as wide as possible and still be able to service tank.
50-12-17	D1, (1) Adjustable Shelf SHOP NOTE: Install between the front wall and the vertical divider. Mount 44" up from the floor.

PART NO	DESCRIPTION
	<p>Mount (2) compt. lights under the adjustable shelves and not into the compartment sidewalls. Leave extra wire tied neatly next to the uni-strut track so shelves can be adjusted.</p> <p>NOTE: Shelf to have 1" lip on all four sides</p>
50-14-03	<p><i>D2, (1) Adjustable Shelf</i> SHOP NOTE: Mount compt. lights under the adjustable shelves and not into the compartment sidewalls. Leave extra wire tied neatly next to the uni-strut track so shelves can be adjusted.</p> <p>NOTE: Standard in 2006 conversion</p>
50-16-18	<p><i>D4, (1) Adjustable Shelf</i> SHOP NOTE: Mount compt. lights under the adjustable shelves and not into the compartment sidewalls. Leave extra wire tied neatly next to the uni-strut track so shelves can be adjusted.</p> <p>NOTE: Standard in 2006 conversion</p>
50-18-27	<p><i>P5, (1) Vertical Backboard Divider, Lynex Coated</i> SHOP NOTE: LOCATION: In P-5 Ext. Compt. - 15" from the front wall. Full Height vertical divider. DO NOT LINE WITH RUBBER - LYNEX ALUMINUM FINISH.</p>
50-18-48	<p><i>P5, [2] Adjustable Shelves</i> SHOP NOTE: DO NOT LINE WITH RUBBER - LYNEX ALUMINUM FINISH Bottom shelf to be 37" ID up from floor Second shelf to be 17.5"ID up from the 1st shelf. Shelves to be 1 " lip on all four sides</p> <p>NOTE: Mount (2) compt. lights under the adjustable shelves and not into the compartment sidewalls. Leave extra wire tied neatly next to the uni-strut track so shelves can be adjusted.</p>
50-19-04	<p><i>SCBA Mounting PLATES - 24" each</i> SHOP NOTE: Mounting Location: MOUNT ONE IN D-4 AND ONE IN P-5 AT FLOOR LEVEL SEE PRINTS</p> <p>ENG. NOTE: Specify mounting location</p>
50-22-04	<p><i>Reflectors On Interior of All Exterior Compartment Doors</i> SHOP NOTE: INSTRUCTION: Red Reflector 1" x 4.5"</p>

PART NO	DESCRIPTION
50-24-04	No Exterior 16" Grab Rail Required At This Time SHOP NOTE:
50-27-04	Weld & Finish Side Seams
50-32-08	Bumper, Rear With 7" Diamond Back Flip Step SHOP NOTE: 94" Wide x 12" Deep, 7" FLIP STEP Full Width ADP Kickplate below the rear entry doors Step with diamond back tread.
50-34-06	Bumper Pods, Cast Aluminum With Logo
50-38-06	Body Protection, Rear Mudflaps & "C" Channel Rubrails SHOP NOTE: "Pierce" style "C" channel rubrails.
50-40-02	<input checked="" type="checkbox"/> Fuel Entry and Step, PASSENGER Side Under Cab Door, ADP SHOP NOTE: Option #4 Medtec Standard with 2nd step option and diamondback step insert on bottom step (T00009J w/T00006J) NOTE: 2-8-07 Customer supplied chassis change to passenger side
50-40-20	Standard Driver and Passenger Step Under Cab Door - Intl. SHOP NOTE: With Grip Strut
50-42-28	<input checked="" type="checkbox"/> Stoneguards, ADP 21" Front - 16.5" Rear SHOP NOTE: ENG. NOTE: AD 166 & AD 170
50-44-02	<input checked="" type="checkbox"/> Fenderettes, Rear, Stainless Steel
50-45-02	<input checked="" type="checkbox"/> Battery Cover and Step, Under DRIVER Cab Door, ADP SHOP NOTE: <input checked="" type="checkbox"/> ROLL OUT TRAY FOR BATTERIES - Option #4 <input checked="" type="checkbox"/> Flip Down w/slide out tray. Medtec standard w/2nd step option (16") & diamondback step insert on bottom step.
50-46-08	<input checked="" type="checkbox"/> License Plate Holder #LP0002-1, Recessed On Driver's Side SHOP NOTE: LOCATION: With (2) top lights. Rear drivers side, below turn signal.
50-48-02	<input checked="" type="checkbox"/> Mudflaps On Rear, With Manufacturer's Logo
50-50-02	<input checked="" type="checkbox"/> Ziebart Undercoating, Chassis & Body (Standard)
*** INTERIOR PATIENT COMPARTMENT COMPONENTS ***	
SHOP NOTE: >>>All drawers are to be retrofitted with the 250 pound drawer slides with extra lips, except any airway drawers<<<	
NOTE:	

PART NO	DESCRIPTION
	>>>NO WOOD PRODUCTS<<<
52-05-06	<p><i>Cabinet Glass - 1/4" Smoked Lexan - ALL</i> SHOP NOTE: ALL CABINET GLASS TO BE LEXAN ILOS PLEXI with the exception of the ALS cabinet</p> <p>ENG. NOTE: Specify which cabinets. Check with factory for pricing.</p>
52-06-02	<p><i>Stainless Steel Round Southco Locking Latches, Standard</i> SHOP NOTE: INSTRUCTION: All interior cabinet doors to have, Stainless steel locking round Southco latches.</p>
	<p>NOTE: >>Standard option with 2006 Conversion<<<</p>
52-11-08	<p><i>Cabinetry, Patient Compt, Aluminum With Formica (Radius)</i> SHOP NOTE: INSTRUCTION: -- 5" RADIUS CORNERS --ON STREETSIDE & UPPER CURBSIDE CABINETS ONLY. DELETE RADIUS ON THE ALS CABINET >>>NO WOOD PRODUCTS<<<</p>
52-18-06	<p><i>Countertops, Stainless Steel, 1st Action Area</i> SHOP NOTE: WITH 1" LIP AND SEALED CORNER</p> <p>ENG. NOTE: Specify "Pan" or "Flat" style.</p>
52-18-08	<p><i>Countertops, Stainless Steel, 2nd Action Area</i> SHOP NOTE: USE FLAT STYLE HERE</p> <p>ENG. NOTE: Specify "Pan" or "Flat" style.</p>
52-28-12	<p>✓ <i>Dome Lights, (6) + (3) 18" Fluorescents</i> SHOP NOTE: INSTRUCTION: ✓ (2) - 3 position switches in the rear switch panel (1) for each bank of lights. A three-minute time delay system activated by the patient entry doors. ✓ (3) #736 Thinlite brand RECESSED 18" fluorescent lights to be installed. (Cut out size for fluorescent lights to be 5.25" x 19.25") ✓ (1) On/off switch in the rear switch panel, for both lights.</p>
52-32-02	<p>Ceiling In Patient Compt, Pads Over Center Access SHOP NOTE: INSTRUCTION: The ceiling to have access to antennae bases/leads. Covered by center ceiling pads.</p>
52-34-04	<p><i>Conduit, 2" FLEXIBLE</i></p>

PART NO	DESCRIPTION
	<p>SHOP NOTE: INSTRUCTION: (1) 2" flex conduit to run, from behind DRIVER cab seat, underneath vehicle, to the 1st action area, behind right side access panel.</p>
52-36-06	<p>✓ <i>Thinlite Light, 18" - Surface Mount In 1st Action Area</i> SHOP NOTE: MAKE SO WIRES ARE COVERED FROM UNDERSIDE FROM THE LIGHTS</p> <p>Adding a separate switch for each you will loose your spare and have no open switches.</p> <p>NOTE: There shall be a switch for both front & rear Thinlites in the rear switch panel.</p>
52-38-04	<p>✓ <i>Thinlite Light, 18" - Surface Mount 2ND Action Area</i> SHOP NOTE: SEE PRINT FOR LOCATION There shall be a switch for both front and rear AA Thinlites in the rear switch panel.</p>
52-48-06	<p>✓ <i>Timer System For Ceiling Fluorescent Lights - Rotary</i> SHOP NOTE: INSTRUCTION: ✓ Install timer on curbside wall, beside side entry door. Timer to be set up for 0 - 60 minutes.</p> <p>ENG. NOTE: Specify location.</p>
52-50-06	<p>✓ <i>Gooseneck Light, 12" - Surface Mount - FRONT CONSOLE</i> SHOP NOTE: INSTRUCTION: FEDERAL 12" LITTLE LIGHT ON PASSENGER SIDE OF FRONT CONSOLE</p> <p>ENG. NOTE: Specify location.</p>
52-54-22	Flooring, With 5" Roll-up
52-60-04	Rear Threshold, 6" Wide Stainless Steel With 2" Skid tape
	<p>SHOP NOTE: INSTRUCTION: 6" wide stainless steel threshold with 2" wide skid tape covering the threshold screw heads.</p>
52-62-18	<p><i>Interior Risers On Squad Bench & Streetside, Standard Height</i> SHOP NOTE: INSTRUCTION: Standard Height stainless steel on; - the squad bench face and end - the lower section of the streetside cabinet, to just below the bottom of the T-bar.</p> <p>***INTERIOR COLOR SECTION***</p> <p>SHOP NOTE: >>>NO WOOD PRODUCTS<<<</p>

PART NO	DESCRIPTION
53-02-12	<i>Formica Color, Fog (#961) (Grey)</i> SHOP NOTE:
53-03-04	<i>Polished Formica Finish</i> SHOP NOTE:
53-06-44	<i>Flooring Color, Onyx #150, LonCoin II Flecks (Black)</i> SHOP NOTE:
53-33-04	<i>Upholstery Color,EVS Brand Gunmetal #MV102&#CN202 Brown/Grey</i> SHOP NOTE: INSTRUCTION: EVS Gunmetal #MV102 Vacuum Formed Cushions For The Following: Tech Seat, CPR Seat & Backrest, Squad Bench Seat & Backrest. Matching EVS Gunmetal #CN202 For All Trim.
	*** STREETSIDE CABINETS - PATIENT COMPARTMENT ***
	SHOP NOTE: >>>NO WOOD PRODUCTS<<<
54-02-38	✓ <i>Sect 1 - 1st Action Area With 3/4" Lip</i>
54-04-02	✓ <i>Sect 1, Action Area Control Panel, Cabinet</i> SHOP NOTE: INSTRUCTION: ✓ <i>ROCKER style switch panel. Angled switch panel @ 30 degree angle in upper part of 1st action area. Action Area will raise to accommodate the cabinet under the Action Area with special ID requirements</i>
54-12-10	✓ <i>Sect 1, No Clock In Rear Action Area At This Time</i> SHOP NOTE:
54-16-26	<i>Sect 1, 1st AA Overhead Cabinet</i> SHOP NOTE: INSTRUCTION: NO Fixed center divider (1) adjustable shelf
54-18-06	<i>Sect 1, Restocking Lexan Doors On Overhead Cabinet</i> SHOP NOTE: LOCATION: On the cabinet above 1st action area.
54-20-02	Sect 1, Handles, Full Length Aluminum SHOP NOTE: LOCATION: On the cabinet above 1st action area.
54-26-12	<i>Sect 1, Writing Tray, 1" H x 14" W</i> SHOP NOTE:

PART NO	DESCRIPTION
54-30-26	<p><i>Sect 1, Cabinet Below 1st AA 9" H x 54" W</i> SHOP NOTE: RAISE ACTION AREA IF NEEDED TO GET 9.5" ID OPENING Full Length and Width cabinet NO Fixed center divider No shelves</p>
54-32-02 54-34-02	<p><i>Sect 1, Sliding Lexan Doors On Cabinet Below 1st AA</i> Sect 1, Handles, Full Length Aluminum SHOP NOTE: LOCATION: On the cabinet below 1st action area.</p>
56-02-08	<p><i>Sect 2, Sharps & Waste Compartment, TiltOut, Full Depth</i> SHOP NOTE: INSTRUCTION: Rearward of the CPR seat with Round locking SS Southco latch & holdopen.</p>
56-04-05	<p><i>Sect 2, Single Cabinet Above CPR Seat,</i> SHOP NOTE: INSTALL ROUND SOUTHCO SS LATCH AT BOTTOM INSTALL [1] ADJUSTABLE SHELF IN CABINET</p>
56-06-10 56-08-14	<p><i>Sect 2, Flip-up Lexan Door On Cabinet Above CPR</i> <i>Sect 1, Handles, Stainless Steel Round Southco latch</i> SHOP NOTE: Centered at bottom of door</p>
56-26-04 56-26-10	<p>SECOND ACTION AREA 22"W x 20"H <i>Sect 2, 2nd Action Area, Locking Drug Drawer</i> SHOP NOTE: INSTRUCTION: A locking drug drawer shall be installed on top of the second action area countertop with locking SS round southco latch. INSTALL THREE [3] DIVIDERS IN DRUG DRAWER, front to back</p>
58-02-08	<p><i>Sect 3, Overhead Cabinet, Rearward</i> SHOP NOTE: INSTRUCTION: NO center divider (1) adjustable shelf</p>
58-04-06	<p><i>Sect 3, Restocking LEXAN Doors, Rear Overhead Cabinet</i> SHOP NOTE:</p>
58-06-02	<p>Sect 3, Handles, Full Length Aluminum SHOP NOTE: LOCATION: On the upper rear streetside overhead cabinet.</p>
58-46-04	<p>Sect 3, L/S Exhaust Fan, 6" W x 8" H, 240 cfm Air Flow SHOP NOTE: INSTRUCTIONS: <input checked="" type="checkbox"/> Install (1) standard exhaust fan - streetside rear. <input checked="" type="checkbox"/> Install a fan speed switch in rear switch panel.</p>

*** BULKHEAD COMPONENTS ***

PART NO	DESCRIPTION
	<p>SHOP NOTE: >>>NO WOOD PRODUCTS<<<</p>
60-02-02	<p><i>B1, L/S, Oxygen Compt, Interior Access With 0/2 View Window</i> SHOP NOTE: INSTRUCTIONS: Hinged LEXAN door for 0/2 view into D-1 compartment.</p>
60-02-08	<p>✓ <i>B1, L/S, Electrical Cabinet, Angled</i> SHOP NOTE: INSTRUCTION: ✓ An angled cabinet shall house the electrical components.</p>
60-04-02	<p>✓ <i>B1, Electrical Cabinet Door With Round Locking Southco Latch</i> SHOP NOTE: INSTRUCTION: ✓ Door vented at the top and the bottom with locking SS Round Southco latch. HINGE ON SIDE TOWARD PASS THRU WINDOW</p>
60-08-04	<p>✓ <i>B1, Thermostat, Digital, Hoseline, #CM3000 w/ Manual Control</i> SHOP NOTE: LOCATION: ✓ On 1st action area wall.</p>
60-11-02	<p>· <i>B1/2, Cab/Body Pass-Through</i> SHOP NOTE: LOCATION: Pass-thru between cab and module. WITH SLIDING LEXAN WINDOW</p> <p>INSTRUCTION: There shall be a pass-through access window approx. 16"H x 17.5"W with a sliding Lexan window, in formica covered NON-wood frame.</p>
60-12-80	<p>✓ <i>B1/2, Heat/Cool Unit, Patient Compt, Hoseline #1131 w/Ultra</i> SHOP NOTE: INSTRUCTION: ✓ Mounted over passthru. ✓ Double vents on underside of HVAC Cabinet ✓ Controls to be located in the rear switch panel.</p> <p>STANDARD LOCATION WITH UV LIGHT OPTION USE HOSELINE UNIT FOR COMPATIBILITY</p> <p>Old Sytem not attached to any model</p> <p>ENG. NOTE: Old Sytem not attached to any model</p> <p>NOTE: HVAC - Hoseline APS 253 Ultraviolet Air Purification system--to be used on Hoseline system only per Dale Jacobs. This is an adder to the system</p>
60-12-99	<p>✓ <i>B1/2, FRESH AIR INTAKE</i> SHOP NOTE: ✓ MOUNT FRESH AIR INTAKE ON FRONT OF BOX BEHIND THE HEAT/AC UNIT WITH A PUSH PULL ✓ SHUT-OFF VALVE IN IT</p>
60-14-08	<p>✓ <i>B1/2, A/C Condenser, Bottom Mounted, BMC 1006 With Dryer</i> SHOP NOTE: INSTRUCTIONS: ✓ Install an auxiliary A/C condenser under body.</p>

~~check~~ →
 OK
 see
 right
 show
 vents
 go

PART NO	DESCRIPTION
63-44-99	<p>Connect to the standard interior Heater Air Conditioner combination unit.</p> <p>B2, SPECIAL - ALS Cabinet , SHOP NOTE: See Previous Unit 5749 >>>NO WOOD PRODUCTS<<<</p> <p>Top: 43.5" H x 32" W, aluminum Diamond slat Auto roll-up door (must be auto roll per engineering to provide clearance for electrical outlets) locking bar latch, [1] adjustable shelf (No Lip on Shelf) 16" up from the floor of the compartment</p> <p>Center Drawer: 10" H x 32" W brushed aluminum face, drawer Locking Round SS Southco latch,</p> <p>Bottom: 17" H x 32" W, dual solid formica covered NON-wood doors Locking Round SS Southco latches, top@ juncture</p> <p>Rubbermat on the bottom of each cabinet section, drawer, and shelf. Install lip on backside of inner most door -so door will not open w/o outward door opened first.</p> <p>No Radius.</p> <p>ENG. NOTE: Special configuration. Contact factory for pricing and availability prior to offering to customer. If "clear opening" dimensions required - these must be specified.</p> <p>NOTE: Minimum required dimensions specified by dealer: Upper: 34" H x 22" W Locking Drawer: 8" Depth Lower Double Door: 14" H x 24" W</p>
63-70-99	<p>B1/2, Special NITROUS CABINET SHOP NOTE: Install a cabinet 14"W X 17"D X 18"H with a flip-up formica covered aluminum door, hinged toward the ALS cabinet with a gas strut hold open. Flip up...Build like their previous unit 5749 Install cabinet next to ALS cabinet, under the pass-thru window.</p> <p>Separate key lock on top.</p> <p>Install metal angle on corners of cabinet Dealer to supply and install bottle brackets for interior of this cabinet.</p> <p>ENG. NOTE: Special configuration. Contact factory for pricing and availability prior to offering to customer.</p>
64-01-12	<p style="text-align: center;">*** PATIENT COMPARTMENT SEATING ***</p> <p>SHOP NOTE: >>>NO WOOD PRODUCTS<<<</p> <p>Vacuumed Formed Upholstery (AD166 AD170 AD180 PD156 PD168) SHOP NOTE: INSTRUCTION:</p>

PART NO	DESCRIPTION
	EVS Vacuum formed seats & backrests only. Armrests and all trim panels to be machine stitched using EVS Companion II material.
64-04-06	Sect 1, Att. Seat, EVS Child Seat, On Swivel Base (VF) SHOP NOTE: INSTRUCTION: EVS seat with built-in child safety seat. EVS 185S swivel type seat base. NO ARMREST.
64-06-18	Sect 2, CPR Seat, 26" Wide With Fold Down Backrest
64-07-02	Sect 2, Storage Under CPR Seat - Hinged on aisle SHOP NOTE: INSTRUCTION: Seat cushion hinged on aisle side, by the cot.
64-10-36	Sect 2/3, Squad Bench, 22" D x 74" W x 16" H SHOP NOTE: INSTRUCTION: (2) lids with storage under both sections. Gas strut hold opens and [2] paddle latches.
64-14-02	Sect 2/3, Back Rests, (2) Above Squad Bench SHOP NOTE: Both backrests are cut back for the armrest and switches.
64-16-02	Sect 2, No Posts and Cups Required At This Time SHOP NOTE:
64-18-15	Sect 2, Armrest, "Mansaver", Squad Bench SHOP NOTE: INSTRUCTION: ATTENTION FAB: REINFORCE BACK WALL . Install mansaver armrest on aluminum, formica covered plate, on squad wall - in line with squad backrest. Vinyl cover with ziptie closer on armrest.
64-22-06	Sect 2, Sharpss, Front of Sqd Bnch, Tilt-out SHOP NOTE: INSTRUCTION: At head end on isle side. Sharpes container will be installed. TIP OUT with round locking SS Southco latch. INSTALL KENDALL#85131 SHARPES CONTAINER MOUNTED TO THE DOOR---NOT TO BE FULL DEPTH FOR SLIDE OUT AT HEAD OF BENCH
64-22-99	Sect 2, Waste, Front of Sqd Bnch, Slide out Drawer SHOP NOTE: Stepwell Side of squad bench. Large waste container only. Round SS locking southCo Latch.
	*** CURBSIDE CABINETS - PATIENT COMPARTMENT ***
	SHOP NOTE: >>>NO WOOD PRODUCTS<<<
68-10-32	Sect 2/3, Squad Bench Cabinet, Two-Section SHOP NOTE: INSTRUCTION:

PART NO	DESCRIPTION
	Cabinet to be divided into (2) sections by a fixed center divider.
68-12-08	<p><i>Sect 2/3, Restocking LEXAN Doors, Sliding Flip Up</i> SHOP NOTE: LOCATION: On Squad Overhead Cabinet</p> <p>ENG. NOTE: Specify how many windows required.</p>
68-14-14	<p>Sect 2/3, Handles, Full Length Aluminum SHOP NOTE: LOCATION: On the squad overhead cabinet doors.</p>
68-16-00	Sect 3, No Inside/Outside Access P-5 Required At This Time
*** PATIENT COMPARTMENT EQUIPMENT/COMPONENTS ***	
70-02-10	<p><i>IV Holders, (3) Cast Products #2008-1, Ceiling Mounted</i> SHOP NOTE: LOCATION: (2) over cot (1) over squad bench (1) had been Deleted MOUNT PER PRINT</p>
70-10-02	<p><i>Cot Mount, Ferno-Washington #175-4 Dual Position, Removable</i> SHOP NOTE: INSTRUCTION: For Cot Model: 93P (for positioning of cot mounts only)</p>
70-14-06	<p>Cot Mount Location, Side & Center ENG. NOTE: Specify Customer's Cot Model (For Positioning Only - Cot Not Included)</p>
70-16-06	<p><i>Cot Wheel Plates, (3) S/Steel (FW #93P)</i> SHOP NOTE: INSTRUCTION: For Cot Model 93P (for positioning of stainless steel, cot plates only)</p> <p>ENG. NOTE: Please Specify Cot Model in Note Section.</p>
70-17-02	No Cot Stop Required at This Time
72-02-12	<p>Assist Rails, (1) 90" x 1.5", (1) 60" x 1.5", Brey Krause SHOP NOTE: INSTRUCTION: (1) 90"x 1.5" - over cot. (1) 60" x 1.5 " - over squad bench.</p>
72-08-06	<p><i>Grab Rails, (2) Interior, 16" x 1.5" Brey Krause</i> SHOP NOTE: INSTRUCTION: NSTRUCTION; (2) 16" x 1.5" grab rail(s) bolted in place.</p>

PART NO	DESCRIPTION
72-10-02	<p>Use Brey-Krause Smooth Style (1) on ALS cabinet next to side entry door. (1) at rear doors on curbside. SEE PRINTS</p> <p>ENG. NOTE: Medtec Style. Select quantity of two (2) or more. Specify locations.</p> <p>Signs, "No Smoking Oxygen Equipped" & "Fasten Seatbelts" SHOP NOTE: LOCATION: (1) on 1st action area wall.</p>
<p>*** MEDICAL OXYGEN & ENVIRONMENTAL SYSTEMS ***</p>	
74-02-02 74-02-06	<p>Oxygen, 3000 Liters Minimum Oxygen, (2) Outlets - 1st Action Area & Squad SHOP NOTE: INSTRUCTION: (1) on the 1st action area wall (1) over squad bench, head end of overhead cabinet SEE PRINTS</p>
74-04-04	<p>Oxygen Outlet, (1) Additional, Specify Location SHOP NOTE: INSTRUCTION: (1) additional outlet in the ceiling. SEE PRINT</p>
74-04-12	<p>Oxygen Outlets to be Cemtron/NCG Brand SHOP NOTE:</p>
74-06-06	<p>Flowmeter, (1) Oxygen, Gravity Type SHOP NOTE: LOCATION: SHIPPED LOOSE</p>
74-10-06	<p>Regulator, Oxygen SHOP NOTE: LOCATION: On O₂ hose in D-1 compartment.</p>
74-14-06	<p>Gauge, Digital Oxygen Content With Alarm SHOP NOTE: LOCATION: In 1st action area.</p> <p>ENG. NOTE: Medtec brand.</p>
74-16-04	<p>Monitor, Carbon Monoxide With Alarm--Specify Location SHOP NOTE: At foot of squad bench on wall of Backboard compartment. P-5 - upper section</p> <p>ENG. NOTE: Specify Location</p>
74-18-04	<p>Oxygen Shut-Off, Electric Solenoid With Manual Bypass</p>

PART NO	DESCRIPTION
74-20-08	<p>SHOP NOTE: INSTRUCTION: Manual by-pass valve on 1st action area wall. (1) switch in the rear switch panel.</p>
74-20-08	<p>Suction & Aspiration Systems, SSCOR/Thomas, D2 SHOP NOTE: INSTRUCTION: [1] SSCOR 20001/02 disposable canister, stainless bracket and wall-mount vacuum gauge and outlet are located on the 1st AA wall. See print.</p> <p>Install the Thomas brand vacuum pump in the upper left corner of the D-2 compartment in a metal cage. Make cage as small as possible leaving maximum storage space in this compartment.</p>
74-22-02	<p>Sharps & Bio-Hazard Containers, Racksack With Bags SHOP NOTE: LOCATION: SHIPPED LOOSE</p>
<p>*** COMMUNICATION & LOOSE EQUIPMENT ***</p>	
76-02-06	<p>Patient Code Signal System, With (3) Switches & Buzzer SHOP NOTE: LOCATION: Cab console and rear switch panel.</p> <p>ENG. NOTE: Rocker Style to have "buzzer" Soft Style to have "beeps"</p>
76-06-04	<p><i>skip done</i> { Radio Equipment, (3) Teflon coated, White Jacketed SHOP NOTE: INSTRUCTION: Antennae/Radio (3) bases and coax. Power and ground wires. INSTRUCTION; Run From: [1] center front of module roof [1] center center of module roof [1] center rear of module roof.</p> <p>Run To: Under front cab console.</p> <p>NOTE: Label Each Coax 1-2-3 [1] Ignition, [1] Hot all the time [1] ground each</p>
76-08-04	<p>Cell Phone/Radio Equip, (1) Each Pwr & Grnd, Coax Cable SHOP NOTE: INSTRUCTIONS: (1) Antennae base - Run from: Center rear of module roof. Run to: FIRST ACTION AREA w/grommetted SS Plate</p> <p>Use Teflon Coax cable. Label termination point of each radio cable. Cell to be labeled #4</p> <p>ENG. NOTE:</p>

PART NO	DESCRIPTION
	Specify where to run to.
78-02-06	(2) Fire Extinguishers, ABC 5 lb With Mounting Brackets SHOP NOTE: LOCATION: SHIPPED LOOSE
	*** PAINTING, LETTERING & STRIPING ***
80-04-02	Body Surface Preparation with Corrosion Inhibitor
80-04-04	Paint Preparation & Processes
80-04-08	<i>Body Paint Color, Sikkens, Single, White</i> SHOP NOTE: PAINT TO MATCH CHASSIS
84-06-42	<i>Main Scotchlite Stripes, 1-Color, "Flying H"</i> SHOP NOTE: LOCATION: Paint Stripe - Chassis And Body Sides & Rear Body. Beltline to be 'Flying H' Ruby Red Scotchlite (280-82) Horizontal stripe to be 11" high and the angled vertical stripes to be 20"wide. ENG. NOTE: Stripe Width Not To Exceed 11".Specify location, color. NOTE: >>>>Match Unit 5749<<<< Cut out on cab doors - Dealer will supply shields for installation Received Dealer supplied Shields ??????Date?????
84-07-00	Non Metallic or Pearl Paint Color
84-09-14	<i>Pinstripes, 1.5"W, 1/4" Above/Below, Reflective,</i> SHOP NOTE: 1/4" up to 2" wide pinstripes Specify color and separation LOCATION; 1/4" above and below the main stripe & H design. COLOR & NUMBER; Gold Scotchlite (280-64) ENG. NOTE: Smart gold stripe is an out source product, which requires an upcharge. Please contact factory for pricing.
84-22-00	<i>Pinstripe, 3/4" W -"C" Style Rubrail, Reflective,WHITE</i> SHOP NOTE: SPECIFY COLOR: Install 3/4" wide WHITE reflective stripe through the center of the "C" style rubrail. ENG. NOTE: Smart gold stripe is an out source product, which requires an upcharge. Please contact factory for pricing.
88-04-06	<i>Decals, (1) 32" "Star of Life" Installed on Roof</i> SHOP NOTE: Color:

PART NO	DESCRIPTION
	>>>Install<<< SOL on Roof Standard Intense Blue Vinyl #220/225-47
	NOTE: >>>>NO LETTERING BY MEDTEC<<<<
88-04-99	<i>Decals, Package, DELETE FOR CREDIT</i> ENG. NOTE: Contact Sales Engineering for approval and pricing. Color number required must be supplied with request for availability and pricing. Edit specification to reflect special color shade and number.
	*** MISCELLANEOUS ***
90-02-03	Vehicle Operator's Manual, Hard Cover Binder - AD
90-06-06	Operating Instructions, Video Tape
90-06-09	<i>Electrical Schematics CD - "AS BUILT"</i> SHOP NOTE: >>>>Preliminary Copy to Scott Rusthoven 1-23-06<<<<<< Final Copy sent: 2-16-06
90-07-04	Fuel Fill DEALER ===== DEALER ===== DEALER
97-01-01	<i>AIR PACK BRACKETS</i>
98-00-01	<i>NEIDERMAN EXHAUST HOOKUP</i>
98-01-12	<i>LETTERING PER SPECIFICATION</i>
99-01-04	<i>FLOWTEC DIAL TYPE FLOWMETER AND ADAPTER</i>
99-01-10	<i>LIGHT ACTIVATION PACKAGE</i>
99-01-11	<i>DOOR BUZZER PACKAGE</i>
99-01-14	<i>DUAL FRONT AND REAR MOD-DISCONNECT SWITCHING</i>
99-98-50	<i>KUSSMAUL COILED RETRACTABLE CORDS W/20 FOOT CORD</i> SHOP NOTE: 20 AMP RATED CORDS
99-99-48	<i>ZICO CYBM-1213-40-11</i> SHOP NOTE: FOUR ZICO OXYGEN BRACKETS FOR PORTABLE TANKS
99-99-98	<i>FACTORY INSPECTION TRIP</i>
99-99-99	<i>DELIVERY</i>