



CLEVER PARTS:



Indicators for simple adjustment.



Optional gutter brush, mechanical lifting and lowering.



Hooks - bolted on for easy replacement when using different carriers.



Sprinkler system - the water is injected into the brush roller from behind to minimize dust and save water.



Refuse container hatch for easier cleaning and inspection.

OPTIONS AND ACCESSORIES:

- Gutter brush - right or left
- Support wheel - 3 with moveable attachment point
- Support wheel - 1 for skid steers
- Extra brush roller - for rapid brush replacement