

## F3/C4

- Fully Functional
- Battery (80% or higher)
- Good Condition (Can include light scratching)
- Working Touch or Face ID

## F3/C3

- Small Repair Category
- Good LCD (Can include light scratching)
  - Example #1- (Cracked Housing)
  - Example #2- (Bad battery)
  - Example #3- (Cracked Back Camera)
  - Example #4- (Cracked Housing & Back Camera)
  - Example #5- (Bad Battery and Cracked Housing)
  - Example #6- (Bad Battery & Back Camera)
  - Example #7- (Bad Touch/Face ID (Only Issue))

## F3/C2

- LCD Repair Category
  - Example #1- (Bad LCD Only)
  - Example #2- (Bad LCD & Back Camera)
  - Example #3- (Bad LCD & Battery)
  - Example #4- (Bad LCD & Housing)
  - Example #5- (Bad Touch/Face ID & Cosmetic or Battery Issue)

