

Serial Number: TS-DUO F118

Windows Version: Windows 10 Enterprise LTSC

Version of Teradyne software: 8.0.0.1.6

%System

```
Sys_name = FGBCM-ICT-BE1P;  
SYS_TYPE = TSSYS;  
SYS_PIN_SLOTS = 12;  
SYS_ACCESSORY_SLOTS = 1;  
/* Serial_no = */  
CPU_Type = PC;  
OS_TYPE = WIN10;  
FIRMWARE_REVISION = 7;  
BACKPLANE_ID = 0x87;  
SYS_AVP_DUE_DATE=AVP_1_1_2000;  
8X_SW_Version = R_8_0_0_1_0;  
Receiver_type = BED_OF_NAILS;
```

%RESOURCES

```
dig_control SYS_CNTRLR 1 SLOT=2; /* Integrated System Controller*/  
/* Pin boards 1-9;*/  
pins ULTRAI1_124 1 SLOT=4;  
pins ULTRAI1_124 2 SLOT=5;  
pins ULTRAI1_124 3 SLOT=6;  
pins ULTRAI1_124 4 SLOT=7;  
pins ULTRAI1_124 5 SLOT=8;  
pins ULTRAI1_124 6 SLOT=9;  
pins ULTRAI1_124 7 SLOT=10;  
pins ULTRAI1_124 8 SLOT=11;  
pins ULTRAI1_124 9 SLOT=12;  
functional SFTM 1 SLOT=2, UNLICENSED=SOFTWARE;
```

```
analog ICA 1;  
analog HV_SRC 1;  
pio PIO2 1 SLOT=3;  
ieee IEEE_NI 1;
```

%vpsconfig

```
!configuration file  
!fixedps;  
SYSTEM = FGBCM-ICT-BE2P;
```

```
!slot map  
SLOT(4) = PM07;  
SLOT(3) = PM20;  
SLOT(2) = PM20;  
SLOT(1) = PM20;
```

```
!VPS MAP  
PS(1) = 1;  
PS(2) = 2;  
PS(3) = 3;  
PS(7) = 4;
```